

PIXMA MP750

PIXMA MP780

PARTS

CATALOG

REVISION 0

PIXMA MP750	H12-4562	120V	USA
PIXMA MP750	H12-4563	230V	EMB
PIXMA MP750	H12-4564	230V	GB
PIXMA MP750	H12-4565	230V	EUM
PIXMA MP750	H12-4566	120V	CND
PIXMA MP750	H12-4568	230V	AUS
PIXMA MP780	H12-4582	120V	USA
PIXMA MP780	H12-4583	230V	EE/NE
PIXMA MP780	H12-4584	230V	GB/ME/NORD/ZA
PIXMA MP780	H12-4585	230V	AT/CH/DE
PIXMA MP780	H12-4586	230V	WEST
PIXMA MP780	H12-4587	120V	CND/LTN
PIXMA MP780	H12-4588	230V	AUS
PIXMA MP780	H12-4589	230V	AE
PIXMA MP780	H12-4597	230V	CHN

Canon

NOV. 2004

HY8-33A3-000

Application

This manual has been issued by Canon Inc. for qualified persons to learn technical theory, installation, maintenance, and repair of products. This manual covers all localities where the products are sold. For this reason, there may be information in this manual that does not apply to your locality.

Corrections

This manual may contain technical inaccuracies or typographical errors due to improvements or changes in products. When changes occur in applicable products or in the content of this manual, Canon will release technical information as the need arises. In the event of major changes in the contents of this manual, Canon will issue a new editions of this manual.

The following paragraph does not apply to any countries where such provisions are inconsistent with local law.

Trademarks

The product names and company names described in this manual are the registered trademarks of the individual companies.

Copyright

This manual is copyrighted with all rights reserved. Under the copyright laws, this manual may not be copied, reproduced or translated into another language, in whole or in part, without the written consent of Canon Inc.

Copyright © 2004 by Canon Inc.

CANON INC.

InkJet MFP Quality Assurance Div.

5-1 Hakusan 7-Chome, Toride-city, Ibaraki 302-8501, Japan

DTP System

The data contained on this manual were created using Windows 2000 computers.
Document creation and page layout were performed using Adobe® PageMaker® 6.5.
Logos and illustrations were created using Adobe® Illustrator® 10.0J.

I. CONTENTS

1. ILLUSTRATION INDEX
2. PARTS LAYOUT & PARTS LIST
3. TOOL
4. NUMERICAL INDEX

II. ABOUT THIS MANUAL

1. ILLUSTRATION INDEX

For illustration index, the parts layout illustrations in this parts catalog are listed in abbreviated form in order of illustration number to identify the pages they appear on. To find an illustration of a part, see the ILLUSTRATION INDEX.

2. PARTS LAYOUT & PARTS LIST

Parts layout illustration

a) Parts search

Find a part from the parts layout illustration and find its key number from the parts list to identify the part number and name.

Further, screws, nuts, washers, grip rings, pins and spacers are mentioned in the parts list.

Note: If parts have the same or similar shape but different specifications, their key number is assigned to several part numbers and names in the parts list.

b) Parts replacement procedure

The parts layout illustrations are arranged according to the disassembly procedure of the product. When a unit in the illustration can be disassemble further, a reference illustration page of the disassembly will be included.

The letters (A , B etc.) in the illustration indicate the connection locations of cables and screws.

Parts list

a) FIGURE & KEY No.

The FIGURE & KEY No. column corresponds to the key numbers assigned to the parts in the parts layout illustration.

It also corresponds to the part locations printed on the PC board.

b) PART NUMBER

The PART NUMBER column gives the part numbers corresponding to the key numbers. To order a part, indicate the part number clearly.

Note: Parts marked NPN are not service parts.

c) RANK

The service parts with N in the RANK column are order parts.

d) QTY

The QTY column gives the number of parts in the corresponding components layout illustration.

e) DESCRIPTION

The DESCRIPTION column gives the part names in English.

To order a part, indicate the part name, too.

3. TOOL

This is a list of tools used for servicing products.

4. NUMERICAL INDEX

All the parts listed in this parts catalog are arranged in order of part number. You can identify part locations and names from the NUMERICAL INDEX.

This page intentionally left blank

1. ILLUSTRATION INDEX

FIGURE 1	PIXMA MP750/MP780 PACKAGE CONTENTS	See Page 2-1	FIGURE 2	OUTER COVER, DOCUMENT FEED ASS'Y	See Page 2-5
FIGURE 3	SCANNER UNIT, MIDDLE FRAME	See Page 2-7	FIGURE 4	SPCNT BOARD ASS'Y, NCU BOARD ASS'Y, PAPER EXIT TRAY ASS'Y	See Page 2-9





FIGURE 5	PRINT & ASF, INK ABSORBER, BOTTOM FRAME ASS'Y	See Page 2-11	FIGURE 6	DOCUMENT FEED ASS'Y (1)	See Page 2-13
					
FIGURE 7	DOCUMENT FEED ASS'Y (2)	See Page 2-15	FIGURE 8	DOCUMENT FEED ASS'Y (3)	See Page 2-17
					








FIGURE 9 DOCUMENT FEED ASS'Y (4)	See Page 2-19	FIGURE 10 PRINT ASS'Y, SHEET FEED ASS'Y, POWER SUPPLY UNIT, RELAY BOARD ASS'Y	See Page 2-21
			
FIGURE 11 CARRIAGE UNIT	See Page 2-23	FIGURE 12 CARRIAGE MOTOR, PAPER FEED MOTOR	See Page 2-25
			

FIGURE 13 PURGE UNIT, PLATEN UNIT, PAPER FEED ROLLER ASS'Y	See Page 2-27	FIGURE 14 TOOLS	See Page 3-1
			

2. PARTS LAYOUT & PARTS LIST

FIGURE 1 PIXMA MP750/MP780 PACKAGE CONTENTS



PIXMA MP750/MP780 2.PARTS LAYOUT & PARTS LIST

FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
1- 1	HY7-3084-000		1	CORD, POWER SUPPLY (US)	MP750(USA CND) MP780(USA CND/LTN)
	HY7-3085-000		1	CORD, POWER SUPPLY (EURO)	MP750(EUM EMB) MP780(GB/ME/NORD/ZA AE AT/CH/DE WEST EE/NE)
	HY7-3086-000		1	CORD, POWER SUPPLY (CHN)	MP780(CHN)
2 3	HY7-3087-000		1	CORD, POWER SUPPLY (GB)	MP750(GB) MP780(GB/ME/NORD/ZA)
	HY7-3089-000		1	CORD, POWER SUPPLY (AUS)	MP750(AUS) MP780(AUS)
	HC1-2483-000		1	LABEL, DESTINATION	MP780
	NPN		1	INK TANK	
4	NPN		1	INK TANK	
5	NPN		1	INK TANK	
6	NPN		1	INK TANK	
7	NPN		1	INK TANK	
8	HY7-3105-000		1	CORD, MODULAR (JP/US/CND/AE)	MP780(USA CND/LTN AE CHN)
	HY7-3106-000		1	CORD, MODULAR (GB)	MP780(GB/ME/NORD/ZA)
	HY7-3107-000		1	CORD, MODULAR (NORDIC)	MP780(GB/ME/NORD/ZA)
	HY7-3108-000		1	CORD, MODULAR (SE)	MP780(GB/ME/NORD/ZA)
	HY7-3109-000		1	CORD, MODULAR (RJ11)	MP780(GB/ME/NORD/ZA EE/ NE)
	HY7-3110-000		1	CORD, MODULAR (AUS)	MP780(AUS)
	HY7-3111-000		1	CORD, MODULAR (AT)	MP780(AT/CH/DE)
	HY7-3112-000		1	CORD, MODULAR (CH)	MP780(AT/CH/DE)
	HY7-3113-000		1	CORD, MODULAR (DE)	MP780(AT/CH/DE)
	HY7-3114-000		1	CORD, MODULAR (BE)	MP780(WEST)
	HY7-3115-000		1	CORD, MODULAR (NL/ES/PT/GR)	MP780(WEST)
	HY7-3116-000		1	CORD, MODULAR (IT)	MP780(WEST)
	HY7-3117-000		1	CORD, MODULAR (FR)	MP780(WEST)
	HY7-3118-000		1	CORD, MODULAR (RU)	MP780(EE/NE)
9	QA4-1117-000		1	TRAY, CD SUB	MP750(GB AUS EUM EMB) MP780(GB/ME/NORD/ZA AUS AE CHN AT/CH/DE WEST EE/NE)
10	QY6-0049-000		1	PRINT HEAD	

PIXMA MP750/MP780 2.PARTS LAYOUT & PARTS LIST

FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
11	QC1-4249-000		1	TRAY, CD MAIN	MP750(GB AUS EUM EMB) MP780(GB/ME/NORD/ZA AUS AE CHN AT/CH/DE WEST EE/NE)
12	HK1-0586-000	N	1	CD-ROM, PRINTER DRIVER (WIN)	MP750(USA) MP780(USA)
	HK1-0587-000	N	1	CD-ROM, PRINTER DRIVER 1 (WIN)	MP750(GB AUS EUM) MP780(GB/ME/NORD/ZA AUS AE CHN AT/CH/DE WEST)
	HK1-0588-000	N	1	CD-ROM, PRINTER DRIVER 2 (WIN)	MP750(GB EUM) MP780(GB/ME/NORD/ZA AT/ CH/DE WEST)
	HK1-0589-000	N	1	CD-ROM, PRINTER DRIVER 3 (WIN)	MP750(EMB) MP780(EE/NE)
	HK1-0590-000	N	1	CD-ROM, PRINTER DRIVER 4 (WIN)	MP750(CND) MP780(CND/LTN)
	HK1-0591-000	N	1	CD-ROM, PRINTER DRIVER (WIN)	MP780(CHN)
13	HK1-0594-000	N	1	CD-ROM, PRINTER DRIVER (MAC)	MP750(USA) MP780(USA)
	HK1-0595-000	N	1	CD-ROM, PRINTER DRIVER 1 (MAC)	MP750(GB AUS EUM EMB) MP780(GB/ME/NORD/ZA AUS AE AT/CH/DE WEST EE/ NE)
	HK1-0596-000	N	1	CD-ROM, PRINTER DRIVER 4 (MAC)	MP750(CND) MP780(CND/LTN)
	HK1-0597-000	N	1	CD-ROM, PRINTER DRIVER (MAC)	MP780(CHN)
14	HT7-0030-000	N	1	BASIC GUIDE (ENGLISH)	MP750(USA AUS) MP780(USA AUS AE)
	HT7-0032-000	N	1	BASIC GUIDE (GB/FR/ES/PT)	MP750(GB CND EUM) MP780(GB/ME/NORD/ZA CND/LTN AT/CH/DE WEST)
	HT7-0041-000	N	1	BASIC GUIDE (DE/IT/NL/GR)	MP750(EUM) MP780(AT/CH/DE WEST)
	HT7-0047-000	N	1	BASIC GUIDE (DK/FI/NO/SE)	MP750(EUM) MP780(GB/ME/NORD/ZA)
	HT7-0052-000	N	1	BASIC GUIDE (CZ/HU/PL/SI/HR)	MP750(EMB) MP780(EE/NE)
	HT7-0058-000	N	1	BASIC GUIDE(RU/UA/EE/LV/LT/GB)	MP750(EMB) MP780(EE/NE)
	HT7-0069-000	N	1	BASIC GUIDE (CHINESE)	MP780(CHN)

This page intentionally left blank

FIGURE 2 OUTER COVER, DOCUMENT FEED ASS'Y




FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
2- 1	HY7-2893-000		1	COVER, LEFT	MP780
	HY7-3079-000		1	COVER, LEFT	MP750
2	HY7-2937-000		1	SPRING, OPEN BUTTON	
3	HY7-2860-000		1	BUTTON, OPEN	
4	HY7-2923-000		1	COVER, RIGHT	
5	HY7-2870-000		1	COVER, CAMERA USB	
6	HY7-2865-000		1	CASSETTE UNIT	
7	HY7-2950-000		1	TRAY, PAPER	

FIGURE 3 SCANNER UNIT, MIDDLE FRAME




FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
3- 1	HY7-3069-000		1	COVER, OPERATION PANEL	MP750(USA CND AUS)
	HY7-3070-000		1	COVER, OPERATION PANEL	MP750(GB EUM EMB)
	HY7-3071-000		1	COVER, OPERATION PANEL	MP780(USA CND/LTN AUS AE)
	HY7-3072-000		1	COVER, OPERATION PANEL	MP780(GB/ME/NORD/ZA AT/ CH/DE WEST EE/NE)
2 3 4	HY7-3073-000		1	COVER, OPERATION PANEL	MP780(CHN)
	HY7-2927-000		1	SCANNER UNIT	MP750
	HY7-3081-000		1	SCANNER UNIT	MP780
	HY7-2920-000		2	RAIL, SCANNER	
	HY7-3074-000		1	COVER, LCD	MP750(USA CND AUS)
	HY7-3075-000		1	COVER, LCD	MP750(GB EUM EMB)
	HY7-3076-000		1	COVER, LCD	MP780(USA CND/LTN AUS AE)
	HY7-3077-000		1	COVER, LCD	MP780(GB/ME/NORD/ZA AT/ CH/DE WEST EE/NE)
	HY7-3078-000		1	COVER, LCD	MP780(CHN)
5	HY7-2949-000		1	SCANNER OPEN ARM ASS'Y	
6	HY7-2939-000		2	SPRING, SCANNER	
7	HY7-2946-000		1	BUSHING, SCANNER, RIGHT	
8	HY7-2900-000		1	FRAME, MIDDLE	
9	HY7-2940-000		1	SPRING, SCANNER ARM	
10	HY7-2853-000		1	ARM, SCANNER SENSOR	
11	HY7-2859-000		1	BUSHING, SCANNER, LEFT	
12	HY7-2871-000		1	COVER, CARRIAGE	

FIGURE 4 SPCNT BOARD ASS'Y, NCU BOARD ASS'Y,
PAPER EXIT TRAY ASS'Y




FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
4- 1	HY7-2905-000		1	NCU BOARD ASS'Y	MP780
2	HY7-2931-000		1	SPCNT BOARD ASS'Y	MP780
	HY7-3082-000		1	SPCNT BOARD ASS'Y	MP750
3	HY7-2861-000		1	CAMERA DIRECT BOARD ASS'Y	
4	HY7-2932-000		1	SPEAKER UNIT	MP780
5	HY7-2930-000		1	SOLENOID	
6	HY7-2866-000		1	CD-R TRAY UNIT	MP750(GB AUS EUM EMB) MP780(GB/ME/NORD/ZA AUS AE CHN AT/CH/DE WEST EE/NE)
	HY7-3068-000		1	CD-R TRAY UNIT	MP750(USA CND) MP780(USA CND/LTN)
7	HY7-2907-000		1	PAPER EXIT TRAY ASS'Y	
8	HY7-3067-000		1	PLATE, LOGO, PIXMA	
9	HC1-2490-000		1	LABEL, SCANNER OPEN	

FIGURE 5 PRINT & ASF ASS'Y, INK ABSORBER,
BOTTOM FRAME ASS'Y






FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
5- 1	HY7-2869-000		1	COVER, BOTTOM, CABLE	
2	HY7-2856-000		1	BOTTOM FRAME ASS'Y	
3	HY7-2890-000		1	ABSORBER, INK	
4	HY7-2889-000		1	ABSORBER, INK	
5	HY7-2888-000		1	ABSORBER, INK	
6	HY7-2887-000		1	ABSORBER, INK	
7	HY7-2891-000		1	ABSORBER, INK	
8	HY7-2886-000		1	ABSORBER, INK	
9	HY7-2885-000		1	ABSORBER, INK	
10	HY7-2953-000		1	ABSORBER, INK	

FIGURE 6 DOCUMENT FEED ASS'Y (1)




[illegible]

FIGURE 7 DOCUMENT FEED ASS'Y (2)



[illegible]

FIGURE 8 DOCUMENT FEED ASS'Y (3)



[illegible]

FIGURE 9 DOCUMENT FEED ASS'Y (4)






FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
9- 1	HY7-2934-000		4	SPRING, BACKUP ROLLER FEED	
2	HY7-2851-000		1	ARM, DETECTION DES	
3	HY7-2901-000		1	MOTOR, DOCUMENT FEED	
4	HY7-2922-000		1	E-RING, PLASTIC	
5	HY7-2857-000		4	BUSHING	
6	HY7-2925-000		1	ROLLER, DOCUMENT FEED	
7	HY7-2924-000		1	ROLLER, DOCUMENT EJECT	
8	HY7-2878-000		1	DOCUMENT GUIDE UPPER UNIT	
9	HY7-2913-000		1	PHOTO INTERRUPTER	
10	HY7-2881-000		1	GUIDE, DOCUMENT FEED	
11	HY7-2945-000		1	WHITE SHEET UNIT	
12	HY7-2942-000		3	SPRING, WHITE SHEET UNIT	
13	HY7-2880-000		1	GUIDE, DOCUMENT EJECT	
14	HY7-2872-000		1	COVER, DOCUMENT EJECT	
15	HY7-2933-000		2	SPRING, BACKUP ROLLER EJECT	

FIGURE 10 PRINT ASS'Y, SHEET FEED ASS'Y,
POWER SUPPLY UNIT, RELAY BOARD ASS'Y



[illegible]

FIGURE 11 CARRIAGE UNIT



[illegible]

FIGURE 12 CARRIAGE MOTOR, PAPER FEED MOTOR





FIGURE & KEY No.	PART No.	R A N K	Q T Y	DESCRIPTION	REMARKS
12 - 1	HY7-2864-000		1	MOTOR, CARRIAGE	
2	HY7-2913-000		1	PHOTO INTERRUPTER	
3	HY7-2902-000		1	LIFT CAM SHAFT ASS'Y	
4	HY7-2938-000		4	SPRING, TORSION	
5	HY7-2917-000		1	PRESSURE ROLLER ASS'Y	
6	HY7-2904-000		2	SPRING, ARM	
7	HY7-2903-000		1	PAPER GUIDE UNIT	
8	HY7-2896-000		1	MOTOR, PAPER FEED	


**FIGURE 13 PURGE UNIT, PLATEN UNIT,
PAPER FEED ROLLER ASS'Y**



[illegible]

3.TOOL

FIGURE 14 TOOLS



4. NUMERICAL INDEX

PART NUMBER	FIGURE & KEY No.	DESCRIPTION	PART NUMBER	FIGURE & KEY No.	DESCRIPTION
CK-8012-000	14 - T1	LUBE, MOLYKOTE HP300 GREASE	HY7-2886-000	5 - 8	ABSORBER, INK
HC1-2483-000	1 - 2	LABEL, DESTINATION	HY7-2887-000	5 - 6	ABSORBER, INK
HC1-2490-000	4 - 9	LABEL, SCANNER OPEN	HY7-2888-000	5 - 5	ABSORBER, INK
HK1-0586-000	1 - 12	CD-ROM, PRINTER DRIVER (WIN)	HY7-2889-000	5 - 4	ABSORBER, INK
HK1-0587-000	1 - 12	CD-ROM, PRINTER DRIVER 1 (WIN)	HY7-2890-000	5 - 3	ABSORBER, INK
HK1-0588-000	1 - 12	CD-ROM, PRINTER DRIVER 2 (WIN)	HY7-2891-000	5 - 7	ABSORBER, INK
HK1-0589-000	1 - 12	CD-ROM, PRINTER DRIVER 3 (WIN)	HY7-2893-000	2 - 1	COVER, LEFT
HK1-0590-000	1 - 12	CD-ROM, PRINTER DRIVER 4 (WIN)	HY7-2896-000	12 - 8	MOTOR, PAPER FEED
HK1-0591-000	1 - 12	CD-ROM, PRINTER DRIVER (WIN)	HY7-2897-000	13 - 1	PAPER FEED ROLLER ASS'Y
HK1-0594-000	1 - 13	CD-ROM, PRINTER DRIVER (MAC)	HY7-2900-000	3 - 8	FRAME, MIDDLE
HK1-0595-000	1 - 13	CD-ROM, PRINTER DRIVER 1 (MAC)	HY7-2901-000	9 - 3	MOTOR, DOCUMENT FEED
HK1-0596-000	1 - 13	CD-ROM, PRINTER DRIVER 4 (MAC)	HY7-2902-000	12 - 3	LIFT CAM SHAFT ASS'Y
HK1-0597-000	1 - 13	CD-ROM, PRINTER DRIVER (MAC)	HY7-2903-000	12 - 7	PAPER GUIDE UNIT
HT7-0030-000	1 - 14	BASIC GUIDE (ENGLISH)	HY7-2904-000	12 - 6	SPRING, ARM
HT7-0032-000	1 - 14	BASIC GUIDE (GB/FR/ES/PT)	HY7-2905-000	4 - 1	NCU BOARD ASS'Y
HT7-0041-000	1 - 14	BASIC GUIDE (DE/IT/NL/GR)	HY7-2907-000	4 - 7	PAPER EXIT TRAY ASS'Y
HT7-0047-000	1 - 14	BASIC GUIDE (DK/FI/NO/SE)	HY7-2913-000	9 - 9	PHOTO INTERRUPTER
HT7-0052-000	1 - 14	BASIC GUIDE (CZ/HU/PL/SI/HR)		12 - 2	
HT7-0058-000	1 - 14	BASIC GUIDE(RU/UA/EE/LV/LT/GB)	HY7-2915-000	13 - 2	PLATEN UNIT
HT7-0069-000	1 - 14	BASIC GUIDE (CHINESE)	HY7-2916-000	10 - 4	POWER SUPPLY UNIT
HY7-2847-000	7 - 4	ADF BOARD ASS'Y	HY7-2917-000	12 - 5	PRESSURE ROLLER ASS'Y
HY7-2849-000	6 - 5	COVER, FRONT, ADF	HY7-2918-000	10 - 1	PRINT ASS'Y
HY7-2850-000	6 - 4	COVER, REAR, ADF	HY7-2919-000	13 - 4	PURGE UNIT
HY7-2851-000	9 - 2	ARM, DETECTION DES	HY7-2920-000	3 - 3	RAIL, SCANNER
HY7-2853-000	3 - 10	ARM, SCANNER SENSOR	HY7-2921-000	10 - 3	RELAY BOARD ASS'Y
HY7-2856-000	5 - 2	BOTTOM FRAME ASS'Y	HY7-2922-000	8 - 5	E-RING, PLASTIC
HY7-2857-000	8 - 6	BUSHING		9 - 4	
	9 - 5		HY7-2923-000	2 - 4	COVER, RIGHT
HY7-2859-000	3 - 11	BUSHING, SCANNER, LEFT	HY7-2924-000	9 - 7	ROLLER, DOCUMENT EJECT
HY7-2860-000	2 - 3	BUTTON, OPEN	HY7-2925-000	9 - 6	ROLLER, DOCUMENT FEED
HY7-2861-000	4 - 3	CAMERA DIRECT BOARD ASS'Y	HY7-2927-000	3 - 2	SCANNER UNIT
HY7-2862-000	11 - 1	CARRIAGE UNIT	HY7-2929-000	8 - 1	SEPARATION ROLLER UNIT
HY7-2863-000	11 - 3	FILM, TIMING SLIT STRIP	HY7-2930-000	4 - 5	SOLENOID
HY7-2864-000	12 - 1	MOTOR, CARRIAGE	HY7-2931-000	4 - 2	SPCNT BOARD ASS'Y
HY7-2865-000	2 - 6	CASSETTE UNIT	HY7-2932-000	4 - 4	SPEAKER UNIT
HY7-2866-000	4 - 6	CD-R TRAY UNIT	HY7-2933-000	9 - 15	SPRING, BACKUP ROLLER EJECT
HY7-2867-000	11 - 2	SPRING, CARRIAGE SHAFT R	HY7-2934-000	9 - 1	SPRING, BACKUP ROLLER FEED
HY7-2868-000	11 - 4	SPRING, CARRIAGE SHAFT L	HY7-2937-000	2 - 2	SPRING, OPEN BUTTON
HY7-2869-000	5 - 1	COVER, BOTTOM, CABLE	HY7-2938-000	12 - 4	SPRING, TORSION
HY7-2870-000	2 - 5	COVER, CAMERA USB	HY7-2939-000	3 - 6	SPRING, SCANNER
HY7-2871-000	3 - 12	COVER, CARRIAGE	HY7-2940-000	3 - 9	SPRING, SCANNER ARM
HY7-2872-000	9 - 14	COVER, DOCUMENT EJECT	HY7-2942-000	9 - 12	SPRING, WHITE SHEET UNIT
HY7-2874-000	6 - 1	TRAY, DOCUMENT	HY7-2945-000	9 - 11	WHITE SHEET UNIT
HY7-2876-000	7 - 3	FRAME, DOCUMENT FEED	HY7-2946-000	3 - 7	BUSHING, SCANNER, RIGHT
HY7-2877-000	7 - 2	DOCUMENT FEED SECTION ASS'Y	HY7-2947-000	6 - 3	ADF COVER ASS'Y
HY7-2878-000	9 - 8	DOCUMENT GUIDE UPPER UNIT	HY7-2948-000	8 - 4	UPPER GUIDE ASS'Y
HY7-2879-000	6 - 2	SLIDER ASS'Y	HY7-2949-000	3 - 5	SCANNER OPEN ARM ASS'Y
HY7-2880-000	9 - 13	GUIDE, DOCUMENT EJECT	HY7-2950-000	2 - 7	TRAY, PAPER
HY7-2881-000	9 - 10	GUIDE, DOCUMENT FEED	HY7-2951-000	10 - 2	SHEET FEED ASS'Y
HY7-2882-000	8 - 2	GUIDE, SEPARATION SHAFT FRONT	HY7-2952-000	10 - 5	PAPER FEED GUIDE ASS'Y
HY7-2883-000	8 - 3	GUIDE, SEPARATION SHAFT REAR	HY7-2953-000	5 - 10	ABSORBER, INK
HY7-2884-000	7 - 1	HINGE, ADF UNIT	HY7-2954-000	13 - 3	BUSHING
HY7-2885-000	5 - 9	ABSORBER, INK	HY7-3061-000	6 - 6	SHEET, DOCUMENT, PRESSURE

PART NUMBER	FIGURE & KEY No.	DESCRIPTION	PART NUMBER	FIGURE & KEY No.	DESCRIPTION
HY7-3063-000	11 - 5	SHAFT, CARRIAGE			
HY7-3064-000	11 - 6	CLIP, CARRIAGE SHAFT			
HY7-3067-000	4 - 8	PLATE, LOGO, PIXMA			
HY7-3068-000	4 - 6	CD-R TRAY UNIT			
HY7-3069-000	3 - 1	COVER, OPERATION PANEL			
HY7-3070-000	3 - 1	COVER, OPERATION PANEL			
HY7-3071-000	3 - 1	COVER, OPERATION PANEL			
HY7-3072-000	3 - 1	COVER, OPERATION PANEL			
HY7-3073-000	3 - 1	COVER, OPERATION PANEL			
HY7-3074-000	3 - 4	COVER, LCD			
HY7-3075-000	3 - 4	COVER, LCD			
HY7-3076-000	3 - 4	COVER, LCD			
HY7-3077-000	3 - 4	COVER, LCD			
HY7-3078-000	3 - 4	COVER, LCD			
HY7-3079-000	2 - 1	COVER, LEFT			
HY7-3080-000	10 - 3	RELAY BOARD ASS'Y			
HY7-3081-000	3 - 2	SCANNER UNIT			
HY7-3082-000	4 - 2	SPCNT BOARD ASS'Y			
HY7-3083-000	13 - 5	FILM, TIMING SLIT DISK			
HY7-3084-000	1 - 1	CORD, POWER SUPPLY (US)			
HY7-3085-000	1 - 1	CORD, POWER SUPPLY (EURO)			
HY7-3086-000	1 - 1	CORD, POWER SUPPLY (CHN)			
HY7-3087-000	1 - 1	CORD, POWER SUPPLY (GB)			
HY7-3089-000	1 - 1	CORD, POWER SUPPLY (AUS)			
HY7-3105-000	1 - 8	CORD, MODULAR (JP/US/CND/AE)			
HY7-3106-000	1 - 8	CORD, MODULAR (GB)			
HY7-3107-000	1 - 8	CORD, MODULAR (NORDIC)			
HY7-3108-000	1 - 8	CORD, MODULAR (SE)			
HY7-3109-000	1 - 8	CORD, MODULAR (RJ11)			
HY7-3110-000	1 - 8	CORD, MODULAR (AUS)			
HY7-3111-000	1 - 8	CORD, MODULAR (AT)			
HY7-3112-000	1 - 8	CORD, MODULAR (CH)			
HY7-3113-000	1 - 8	CORD, MODULAR (DE)			
HY7-3114-000	1 - 8	CORD, MODULAR (BE)			
HY7-3115-000	1 - 8	CORD, MODULAR (NL/ES/PT/GR)			
HY7-3116-000	1 - 8	CORD, MODULAR (IT)			
HY7-3117-000	1 - 8	CORD, MODULAR (FR)			
HY7-3118-000	1 - 8	CORD, MODULAR (RU)			
QA4-1117-000	1 - 9	TRAY, CD SUB			
QC1-4249-000	1 - 11	TRAY, CD MAIN			
QY6-0049-000	1 - 10	PRINT HEAD			
QY9-0057-000	14 - T2	LUBE,FLOIL KG-107A,OIL			

Canon